



BILD - KLANG - EMPFANG

Telefon: 07181-61770 / Fax: 07181-5789

www.dobler.tv / mail@dobler.tv

Programmliste – Sat und Kabel

Taste	SENDER	K/SK	Taste	Sender	K/SK
1	Das Erste	S 24	26	ZDF-Info	S 25
2	ZDF	S 25	27	ZDF-Neo	S 34
3	SWR	S 12	28	ServusTV	S 34
4	Bayerisches	S 02	29	KiKa	S 03
5	NDR	S 02	30	Super RTL	S 02
6	WDR	S 02	31	NICK	S 39
7	MDR	S 02	32	Disney Channel	S 39
8	RBB	S 02	33	SAT. 1 GOLD	S 18
9	Hessen	S 02	34	Sixx	S 02
10	ARD-Alpha	S 39	35	RTL Nitro	S 18
11	Phoenix	S 39	36	RTL Plus	S 37
12	SAT 1	S 13	37	Kabel 1 Doku	S 18
13	RTL	S 13	38	N24 Doku	S 37
14	RTL 2	S 03	39	Prosieben Maxx	S 02
15	Pro7	S 23	40	TELE 5	S 39
16	Kabel 1	S 24	41	DMAX	S 18
17	VOX	S 12	42	BBC	S 15
18	SPORT1	S 24	43	L-TV	S 04
19	EUROSPORT	S 38	44	Regio TV S	S 04
20		S 38	45	VIVA	S 18
21		S 32	46	DELUXE MUSIC	S 21
22	N-tv	S 02	47	HSE 24	S 34
23	N24	S 39	48	QVC	S 34
24	Tagesschau24	S 24	49	QVC Plus	S 11
25	One	S 33	50	Sonnenklar TV	S 12

S 02 = 114 MHz (256 Sym.)

S 13 = 250 MHz (256 Sym.)

S 24 = 330 MHz (256 Sym.)

S 37 = 434 MHz (256 Sym.)

S 03 = 122 MHz (256 Sym.)

S 15 = 266 MHz (256 Sym.)

S 25 = 338 MHz (256 Sym.)

S 38 = 442 MHz (256 Sym.)

S 04 = 130 MHz (256 Sym.)

S 18 = 282 MHz (256 Sym.)

S 32 = 394 MHz (256 Sym.)

S 39 = 450 MHz (256 Sym.)

S 11 = 234 MHz (256 Sym.)

S 21 = 306 MHz (256 Sym.)

S 33 = 402 MHz (256 Sym.)

S 12 = 242 MHz (256 Sym.)

S 23 = 322 MHz (256 Sym.)

S 34 = 410 MHz (256 Sym.)